

KIT BREAKDOWN		
Part Number	Qty.	Description
05-9755	4	Rear Control Arm Spacers
55-01-9755	2	Front Strut Preload Spacer
55-02-9755	2	Front Strut Spacer
55-03-9750	2	Front Sway Bar Bracket
55-03-9755	1	Rear Upper Coil Spacer
55-04-9755	2	Rear Lower Coil Spacer
MS90841	2	Front Sway Bar Links
77-9755	1	Hardware Bag

Step	Part Number	Qty. Per Kit	Description	New Attaching Hardware	Qty. Per Bracket	Hardware Bag Number
<b>FRONT</b>						
15	55-01-9755	2	Front Strut Preload Spacer			
17	55-02-9755	2	Front Strut Spacer	8mm x 15mm bolt, 1.25 pitch 8mm washer 8mm lock washer	3 3 3	77-9755
24	55-03-9750	2	Front Sway Bar Bracket	12mm x 40mm bolt, 1.75 pitch 12mm washer 12mm flange nut, 1.75 pitch	1 1 1	77-9755
25	MS90841	2	Front Sway Bar Links			
<b>REAR</b>						
9	05-9755	4	Rear Control Arm Spacers	14mm x 60mm bolt, 2.0 pitch 14mm washer 14mm lock washer	1 1 1	77-9755
11	55-04-9755	4	Rear Lower Coil Spacer	6mm x 30mm bolt, button head	2	77-9755
13	55-03-9755	2	Rear Upper Coil Spacer			