

Installation Template for 64352

Frame C-Notch Kit

1963-1972 GM Truck

This template is intended to mark the area to be removed for proper fitment.
Cut out and tape to frame rail.

