

Item #	Description	Qty
FR1925MS-S	FRONT STRUT SPACER	2
FB2120RMS-S	REAR STRUT SPACER	2
HB-10MM/NFN	HDWR BAG: STRUT SPACER	2
I-FB2120MSP	INST SHEET: FB2120MSP KITS	1

Item #	Description	Qty
10MMX1.5NFN	10MM X 1.5 N/I FLANGE NUT	6