

<b>Item #</b>	<b>Description</b>	<b>Qty</b>
FB2120FMS-1	FRONT ALUM. SPACER, LOWER	2
FB2120FMS-2	FRONT ALUM. SPACER, UPPER	2
FB2120RMS-S	REAR STRUT SPACER	2
HB-FB2120FMS	HDWR BAG: ALUM. STRUT SPACER	1
HB-10MM/NFN	HDWR BAG: 10MM FLANGE NUTS	1
I-FB2120MSPB	INST SHEET: FB2120MSPB KITS	1

<b>Item #</b>	<b>Description</b>	<b>Qty</b>
10MMX1.5NFN	10MM X 1.5 N/I FLANGE NUT	6

<b>Item #</b>	<b>Description</b>	<b>Qty</b>
10MMX60MMB	10MM X 60MM METRIC BOLT	6
10MMX1.5NFN	10MM X 1.5 N/I FLANGE NUT	6