

No.	Qty.	Part No.	Description
1.	1	137013	Bracket, Power Steering Pump Add-on
2.	1	191103	Hardware Kit

**** Before beginning installation, open all packages and check contents of shipment. Please report any shortages directly to Vintage Air within 15 days. After 15 days, Vintage Air will not be responsible for missing or damaged items.**

1



2

