

Installation Instructions for 40080 Distributor Shim and Bushing Kit

Installation Instructions:

Place the distributor gasket into the top of the aluminum spacer. Place the desired nylon shims onto the base of the aluminum spacer. Place the spacer with the shims and distributor gasket into the intake manifold and install the distributor. The distributor hold down may need to be modified to accommodate the new distributor position.

NOTE: An extra distributor gasket is included.

