

Installation Instructions for 60610 & 60611 U-Bolt Kits

The u-bolts included in this kit should be torqued to 17 ft/lbs. Take care to use the proper torque on these fasteners, since excessive torque can distort the bearing cap and cause failure of the u-joint.



1-800-345-4545 jeps.com