

## ***Installation Instructions for 60664 Driveshaft Loop Mount Kit***

- This kit is designed for installation of JEGS 360 Degree Driveshaft Loop # 555-10660. If used to mount other driveshaft loops, modification may be necessary.
- Mark location to weld the chassis mounting tabs to the chassis. Two(2) tabs are required for each mounting boss which will hold each leg of the driveshaft loop. Spacing must be adequate to allow for the 1" diameter of the boss but not too large to exceed the effective grip length of the #10-32 x 1-3/4" long bolt which is 1-7/16". #10 flat washers can be used as spacers if necessary.
- Have experienced welder of 4130 chrome moly weld the chassis mounting tabs to the chassis. Fit the bosses between the tabs and secure with #10 x 1-3/4" long grip length bolts, washers and nuts. Follow instructions for the 555-60660 kit for completion.



**1-800-345-4545 [jeps.com](http://jeps.com)**