

Installation Instructions for 11110 GM Style Headlight Switch

Installation Instructions:

Wire #	Description
1	Battery input from fuse block
2	Wire going to dash lights
3	Wire going to dimmer switch
4	Wire going to park lights
5	Wire going to tail lights
6	Dome and interior light ground

NOTE: On some switches, wire terminal #4 is omitted. The terminal next to #5 (shown dashed) will become the park light output.

Dome light ground is the terminal to activate the dome light when the switch is turned to the left.

CAUTION: This is a grounding terminal only.

