

Installation Instructions for 10440 & 10445 Fuse Taps

IMPORTANT: Fuse taps are an easy way to add a circuit to an existing fuse block. Care must be taken not to overload the circuit when using these fuse taps. Use a relay for high load items when adding a circuit using the fuse tap.

Installation Instructions:

1. Remove a fuse from the desired circuit.
2. Install the fuse tap over the existing fuse (put it on the side of the fuse that isn't connected to the battery – see the attached photos).
3. Re-Install the fuse into the fuse block
4. Connect the wire to the blade terminal on the fuse tap.

