NOTE:

End may be adjusted <u>up to and no more than 14</u> revolutions out from its bottomed position to help aid in the alignment of the axle.