



Installation Instructions

Rapid Fire Purge Module Kit (82370 R, G, or B)

Thank you for choosing ZEX™. If at any time you have questions regarding this or any of our products, please call our ZEXTEK™ support line at 1-888-817-1008.

Read this installation manual completely before attempting to install your Rapid Fire Purge Module Kit. Failure to do so may result in damage to your vehicle and/or physical harm to yourself. ZEX™ is not responsible for damage or injuries caused by improper use of this kit.



Kit Parts List

<u>DESCRIPTION</u>	<u>QTY.</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
Rapid Fire Module	1	.187 Female Blade Connectors	2
Purge Cloud LED Light	1	.250 Female Blade Connectors	2
20 Amp Relay	1	Ground Rings	5
Red 20 GA. Wire	6ft.	Large Butt Connector	2
Black 20 GA. Wire	6ft.	Small Butt Connector	4

What makes the Rapid Fire Purge Module Kit so cool?

- The ZEX™ Rapid Fire Purge Module pulses your purge kit like a machine gun....heads will turn!
- Includes the award winning Purge Cloud LED light for awesome strobe effects at night!
- Pulses any purge kit on the market...gets the most attention from your purge kit.
- Comes with it's own earplugs, for your protection.

How the ZEX Rapid Fire Purge Module Kit works

Once the activation push-button is depressed, the Rapid Fire Module pulses a relay that is connected to the Purge Solenoid and Purge Cloud LED. The pulsing of the module is what causes the rapid fire effect from the Purge Solenoid and the strobe effect from the Purge Cloud LED.

Installation Inst.

Step 1:

Mount the Rapid Fire Module under the dash of the vehicle.

Step 2:

Mount the Purge Cloud LED at the end of the purge discharge tube. Lock it in place using the set screw that is located on the side of the light's housing.

Step 3:

Wire the Rapid Fire module and the Purge Cloud LED according to the wiring diagram (Fig.A).




Fig. A

WARNING!!!!

The wire leads that are attached to the Purge Cloud LED have a special current limiting resistor factory installed. Do not remove this resistor in an attempt to increase the brightness of the LED. If this is done, the LED will burn out immediately due to current overload. The warranty for the Purge Cloud LED will be voided if the wires from the resistor to the LED have been cut in any way.

Step 4: Enjoy!

After everything has been checked over and the wiring verified to be correct, enjoy your ZEX™ Rapid Fire Purge Module Kit.