



**Performance
Distributors**

HIGH PERFORMANCE & RACING IGNITION SYSTEMS
www.performancedistributors.com
901-396-5782

Ford Sultans of Spark-SOS-Instructions

- 1) First, disconnect your battery cables. Always remove your Negative cable first and install it last.
- 2) Some models may require that you remove your fuel rail on the drivers' side, your power steering pump reservoir bracket, and your starter solenoid bracket.
- 3) Disconnect the coil connector.
- 4) Remove the coil retaining bolt and remove the coil.
- 5) Open up your spark plug gaps to .065" in order to take advantage of the longer duration spark which the SOS Coils produce.
- 6) Install your new SOS Coil over the spark plug. Make sure your boot slides over and fits in place.
- 7) Install your retaining bolt and plug in the connector.

WARRANTY INFORMATION

The Sultans Of Spark, by Performance Distributors, Inc., upon inspection which indicates either materials or workmanship defects, will repair or replace the part in question for a period of one year. This warranty does not cover damage to engine or other parts, personal injury, labor or any other damage or injury. Proof of the sale date to the original consumer is required.