

## INSTALLATION OF AUTOMATIC TRANSMISSION KICKDOWN EXTENSION FOR FORD VEHICLES




1. Install kickdown extension as shown.




2. Bend tabs down to lock extension onto kickdown lever.

## 199R9601

## INSTALLATION OF AUTOMATIC TRANSMISSION KICKDOWN EXTENSION FOR FORD VEHICLES



1. Install kickdown extension as shown.



2. Bend tabs down to lock extension onto kickdown lever.

## 199R9601