

## OPERATION

**CAUTION:** Before each use, check to make sure that chain is engaged and tight. Use only on flat, level, dry surfaces.

- Before using any tool, any part that appears damaged should be carefully checked to determine that it will operate properly and perform its intended function.
- Before using your Shop Stand check for damaged parts.
- Make sure all clamps, locks and bolts are tight.
- Do not use the Shop Stand as a ladder. Never stand on the Shop Stand.
- Never exceed Maximum weight capacity.
- Always engage chain when in use. Never use without chain in place.
- Height and width of Shop stand can be adjusted by attaching different sections of the chain to the J-Bolt. Always use the chain link on each side of the Shop Stand.

### LIMITED WARRANTY

PERFORMANCE TOOL extends only the following warranties, and only to original retail purchasers. These warranties give specific legal rights. Except where prohibited by local law, the law of the State of Washington governs all warranties and all exclusions and limitations of warranties and remedies. There may be other rights which vary from state to state.

PERFORMANCE TOOL warrants the product to be free from defects in materials and workmanship under normal use and service. A defective product may be returned for a free replacement within 90 days from the date of purchase, provided that product is returned to place of purchase immediately after discovery of defect. After 90 days and up to 1 year from date of purchase, PERFORMANCE TOOL will replace at no charge any parts which our examination shall disclose to be defective and under warranty. These warranties shall be valid only when a sales receipt showing the date of purchase accompanies the defective product or defective part(s) being returned. For part(s) after 90 days, please remit your request, postage prepaid to:

PERFORMANCE TOOL, P.O. Box 88259 Tukwila, WA 98138

These warranties exclude blades, bits, punches, dies, bulbs, fuses, and other consumables which must be replaced under normal use and service. These warranties shall not apply to any product or part which is used for a purpose for which it is not design or which has been repaired or altered in any way so as to affect adversely its performance or reliability, nor shall these warranties apply to any product or part which has been subject to misuse, neglect, accident or wear and tear incident to normal use and service.

PERFORMANCE TOOL does not authorize any other person to make any warranty or to assume any liability in connection with its products.

Except for warranties of title and the limited express warranties set forth above, PERFORMANCE TOOL makes no express or implied warranties of any kind with respect to its products. In particular, PERFORMANCE TOOL makes no implied warranty of merchantability and no implied warranty of fitness for any particular purpose, except that for goods purchased primarily for personal, family or household use and not for commercial or business use, PERFORMANCE TOOL makes an implied warranty of merchantability (and, if otherwise applicable, an implied warranty of fitness for a particular purpose), but only for the particular qualities or characteristics, and for the duration, expressly warranted above. The laws on limitation of implied warranties may differ from state to state, so the above limitations may not apply in all cases.

PERFORMANCE TOOL shall not be liable for consequential, incidental or special damages resulting from or in any manner related to any product, or to the design, use, or any inability to use the product. The sole and exclusive remedy for a defective product or part shall be the repair, or replacement thereof as provided above. The laws on limitation of remedies or on consequential, incidental or special damages may vary from state to state, so the above limitations may not apply in all cases.

Copyright ©2014 PERFORMANCE TOOL - All rights reserved

**WARNING:** This product and its packaging contain a chemical known to the State of California to cause cancer, birth defects or other reproductive harm.

# SHOP STAND

Item Number W54024

## OWNER'S MANUAL



Performance Tool®

**PT**  
Performance Tool®

If you encounter any problems or difficulties, please contact our customer service department at:  
1-800-426-1262 between 6:30 a.m. and 4:30 p.m. Pacific time.

## SPECIFICATIONS

Capacity: .....500 lbs.  
 Steel Tubing: ..... 1-1/8 in.  
 Weight: .....15 lbs.  
 Dimensions: ..... 22 x 41.3 x 36.6 in. (assembled)

NOTE: Specifications are subject to change without notice.

## IMPORTANT SAFETY INFORMATION

**WARNING! Read the entire manual to become familiar with the unit BEFORE you use the workbench. Failure to do so may result in personal injury and/or property damage and will void warranty.**

### Warnings:

- DO NOT EXCEED THE MAXIMUM WEIGHT CAPACITY OF 500 LBS.
- DO NOT STAND ON SHOP STAND OR USE AS A SCAFFOLDING SUPPORT.
- Do not use the product if under the influence of alcohol or drugs. Read warning labels on prescriptions to determine if your judgment/reflexes might be impaired.
- Do not wear loose clothing or jewelry as they can be caught in moving parts.
- Protective gloves and non-skid footwear is recommended.
- Wear restrictive hair covering to contain long hair.
- Use eye and ear protection. Always wear: ANSI-approved impact safety goggles.
- Maintain proper footing and balance at all times.

## TOOLS REQUIRED

- 1/2 in. wrench, socket or an adjustable wrench

## PARTS LIST

- Remove all components from packaging and ensure you have all components

| No. | Description         | Qty. | No. | Description      | Qty. |
|-----|---------------------|------|-----|------------------|------|
| 1   | Legs                | 4    | 5   | 5/16-18 Hex Nuts | 10   |
| 2   | Top Frame Pieces    | 2    | 6   | Hex Bolts        | 2    |
| 3   | Chains w/ Eye Hooks | 2    | 7   | Washers          | 14   |
| 4   | J-Bolts             | 2    |     |                  |      |

## ASSEMBLY INSTRUCTIONS

**Note:** Read the entire manual to become familiar with the unit **BEFORE** you use the workbench

**CAUTION:** Metal edges can be sharp; please use extreme caution during assembly.

1. Insert a leg into one of the top frame pieces.
2. Thread a nut onto one of the J-bolts, then place a washer against the nut.
3. Align the holes where the top frame and leg meet and insert the bolt into the hole. Then place another washer and nut onto the exposed end of the bolt.
4. Repeat steps 1-3 for the other side of the top frame and a 2nd leg. Make sure the the "J" portion of the bolts are on the same side.
5. Repeat steps 1-4 for the other 2 legs and top frame using the chains with eye hooks.
6. You should now have two halves of the shop stand. Position each half so the chain and J-bolts face each other.
7. Offset the legs so the holes near the middle of each leg line up on each side.
8. Place a washer on one of the hex bolts and insert through the outside hole of one of the outer legs.
9. Place a second washer between the two legs, insert the bolt through the inside leg, then place a third washer and hex nut.
10. Repeat for the other side. The thread portion of the bolts should face inward.
11. Tighten all nuts and bolts with a 1/2 in. wrench, socket or an adjustable wrench.

