This K&N Airforce Pre-Cleaner must be oiled before using. Use K&N Filter Oil.

#### **INSTRUCTIONS:**

# OILING:

- Saturate the K&N Airforce Pre-Cleaner with K&N Filter Oil.
- Massage until it is fully covered.
- 3. Squeeze, do not wring the excess oil from the K&N Airforce Pre-Cleaner.
- 4. Install the K&N Airforce Pre-Cleaner on the K&N Filtercharger® per the installation instructions.

#### **CLEANING:**

- 1. Remove the K&N Airforce Pre-Cleaner from the K&N Filtercharger<sup>®</sup>.
- 2. Clean with K&N Cleaner or soap and water.
- Air dry before reinstalling on the K&N Filtercharger<sup>®</sup>.

• 1455 CITRUS ST., P.O. BOX 1329, RIVERSIDE, CA., U.S.A. 92502 • TECH SERVICE 800-858-3333 • FAX 951-826-4001 • e-mail: tech@knfilters.com • WWW: http://www.knfilters.com

17245a 10/18/05



This K&N Airforce Pre-Cleaner must be oiled before using. Use K&N Filter Oil.

# **INSTRUCTIONS:**

# OILING:

- 1. Saturate the K&N Airforce Pre-Cleaner with K&N Filter Oil.
- Massage until it is fully covered.
- 3. Squeeze, do not wring the excess oil from the K&N Airforce Pre-Cleaner.
- 4. Install the K&N Airforce Pre-Cleaner on the K&N Filtercharger® per the installation instructions.

#### CLEANING:

- 1. Remove the K&N Airforce Pre-Cleaner from the K&N Filtercharger<sup>®</sup>.
- Clean with K&N Cleaner or soap and water.
- 3. Air dry before reinstalling on the K&N Filtercharger<sup>®</sup>.