


56471 Included Items

- Wire Harness with Tail Light Converter
- Battery Connection Wiring
- Fuse Holder
- Fuse
- Wire Crimp Ends
- Wire Ring Terminal
- Double-Sided Tape Square
- Mounting Hardware
- Wire Ties
- Dust Cover



CIRCUIT PROTECTED CONVERTER SYSTEMS

The product has been 100% tested under the full rated load at the factory. The wire harness installed as part of your tow package includes an electronic module that provides internal circuit protection.

If a short circuit or overload situation occurs in a trailer lighting circuit, the module is designed to shut the circuit down to protect the tow vehicle and module.

If tow vehicle lamps are working but the trailer lamps are not working, shut power off to the faulted circuit for a few seconds then try the circuit again.

If trailer lamps return to normal function the fault has been corrected.

If lamps light for a few seconds and then go off:

1. Check ground wire on both the harness and trailer.
2. Check / correct an overload condition (too many bulbs).

If the circuit fails to light:

1. Check tow vehicle fuses.
2. Check trailer for broken connections.
3. Check the trailer lamp bulbs.
4. Check ground wire on both the harness and trailer.
5. Locate and correct a short.

Note: Using a tester can help confirm system function. If problems persist, see your retailer for assistance with. Important: Check tow lights before leaving and frequently while towing.

ONE-PIECE-34

