

Electrical Connections

- 85-Trigger Wire. Connects to FuelTech Auxiliary Output
(Ground Activation)
- 86-Switched 12-Volt
- 30-Battery (Constant) 12-Volt
- 87-Output for Load (Device) Normally Open 12-Volt