

Installation Instructions for 15177 Fuel Filter/Water Separator

Fuel Tank



Engine



Separator



555-100119 to 100111
555-110119 to 110111
(not included)

Fuel Pump



FUEL INJECTION DIAGRAM

Fuel Tank



Engine



Separator



555-100119 to 100111
555-110119 to 110111
(not included)

Fuel Pump



CARBURETION DIAGRAM

During installation allow enough room for removal and replacement of the element as well as draining the water. Apply a small amount of clean oil to the gasket of the fuel filter when installing. Tighten filter 1/4 to 1/2 turn past full contact between the gasket and the mounting head. Filter elements should be drained approximately every 3000 miles and replaced every 24,000 miles. JEGS Fuel Filter/Water Separator replacement filter p/n 555-15178.



1-800-345-4545 jeps.com