

Installation Instructions Part Number 800-504 2014-15 Polaris Ranger RZR XP 1000 and RZR XP 4 1000 E.F.I.





**1.** It is important to note that the Airaid RZR 1000 Air Filter is installed in the air box differently than the OEM filter.




Installation Instructions Part Number 800-504 2014 -15Polaris Ranger RZR XP 1000 and RZR XP 4 1000 E.F.I.





**1.** It is important to note that the Airaid RZR 1000 Air Filter is installed in the air box differently than the OEM filter.



**1.** Notice the two stops on the mounting tube inside the air box. The first is the stop location for the OEM filter. The second stop, at the wall of the air box, is to be the Airaid stop.



**2.** Install the Airaid filter into the RZR air box as shown, with the mounting flange all the way onto the mounting tube. Tighten the clamp. and reinstall the air box lid.




## Don't Forget Your AIRAID Filter Tune-Up Kit!


P/N 790-551 Aerosol Spray P/N 790-550 Squeeze Spray



AIRAID Filter Co. 2688 E Rose Garden Ln. Phoenix AZ 85050 (800) 498-6951 Airaidinfo@airaid.com www.airaid.com



**1.** Notice the two stops on the mounting tube inside the air box. The first is the stop location for the OEM filter. The second stop, at the wall of the air box, is to be the Airaid stop.



**2.** Install the Airaid filter into the RZR air box as shown, with the mounting flange all the way onto the mounting tube. Tighten the clamp. and reinstall the air box lid.



## **Don't Forget Your AIRAID Filter Tune-Up Kit!**

P/N 790-551 Aerosol Spray P/N 790-550 Squeeze Spray





REV02.23.15