



Push Buttons and Outside Door Handle Assemblies

INSTRUCTIONS



359 Push Buttons

359 - push buttons are sold in pairs work with both 794 and 794A handles. (may require cutting rod)

794 and 794A Handle Assemblies include push buttons, gaskets, and mounting hardware

794 - 1955 - 57 2DR Hardtop, Convertible

794A - 1955 - 57 Nomad, 2DR and 4DR Sedan, 2DR and 4DR Wagon and 1956-57 4DR Hardtop

All 2 door models require 1 pair. All 4 door models require 2 pair.




The Basic Style is found on most
1955 All Models
1956 and 1957 Sedan and Wagons
1957 Convertible and 2DR Hardtop

These Push Rod will work with all handles. The Push Rod may need to be trimmed to fit on the handles that attach to the a lever.



359
Push Button

Match up to original buttons before any cutting is done. Most often they are cut off at notch in rod



The Lever Style is most often found on
1956 Convertible and 2DR Hardtop
1956 and 1957 4DR Hardtop front doors
The push rod will need to be cut to fit.

Reuse Original
Lever Arm