

# PART #864


## 1955-56 Headlight Bezel Seals

### *Instruction Sheet Master*


Revised 12/2017



864 - Headlight Bezel seals are sold in pairs and may require trimming to fit.



1057 - Headlight Bezels are sold as a pair ready to install. They come with 1744 mounting screws and 864 bezel seals.



864 - Headlight Bezel Seals are sold in pairs and may require trimming to fit.

This rubber extrusion is a reproduction of the original. The cutaway view shows the wire core. The seal fits into the headlight bezel and the small flap seals against the seal beam retaining ring. They may need to be trimmed to fit. Install the seal starting at the center bottom of the bezel. Cut the seal to the appropriate length using a pair cutting pliers. The seal ends should just touch each other for best results.