

Directions:

To use, simply place spark plug as shown in the picture and insert desired feeler gauge between ground strap and electrode. Turn knob clockwise until the ground strap is tightly pressed against the feeler gauge. Then turn knob counterclockwise to create space between tool and feeler gauge and remove spark plug.