

1973-87 GM 2WD C10/C20 LS SWAP FULL-LENGTH HEADERS 2334HKR, 2334-1HKR, 2334-3HKR, 2334-7HKR, 2335HKR, 2335-1HKR, 2335-3HKR, & 2335-7HKR Installation Instructions



Thank you for choosing to use HOOKER[™] headers as part of your LS swap project. These headers are part of the most comprehensively engineered system of mounting components, headers and exhaust systems available for this application. The entire Hooker[™] swap system is designed to decrease your total swap installation effort and cost while increasing the engineered quality of your vehicle.

PRE-INSTALLATION CONSIDERATIONS:

Check that the hardware package includes the following:

(12) M8 x 1.25 header bolts

(2) Head flange gaskets

If you are missing any hardware, please contact Technical Service at 1-866-464-6553 or 270-781-9741.

- NOTE: Will not work with factory column shift linkage. Aftermarket column linkage or cable kits such as those offered by Lokar[™] and others will have to be used if you wish to maintain column shift capability of your vehicle.
- **NOTE:** These headers are geometrically/functionally compatible with GM TH350, TH400, 700R4, 2004R, 4L60-4L75 and 4L80E/4L85E automatic transmissions and the OE LS 4th-gen F-body/GTO Tremec T56 and aftermarket T56 Magnum manual transmissions.
- **NOTE:** These headers do not possess a CARB Executive Order Exemption and are therefore not legal for sale or use on pollutioncontrolled motor vehicles.
- **NOTE:** The collector outlets of these headers are designed to be connected to an exhaust system with specific-design Torca 3" coupler clamps, which are included in the Hooker exhaust system kits for this application. These clamps can also be purchased as a pair by ordering Hooker P/N 41173HKR.

The instructions contained in this document assume you have already installed the engine and transmission in the vehicle with the above mentioned HOOKER[™] mounting components per their instructions.

An automotive lift or a jack and jack stands will be required to safely raise and support the vehicle. <u>CAUTION!</u> WORK ONLY ON A LEVEL SURFACE. USE JACKS /JACKSTANDS OF SUFFICIENT CAPACITY TO LIFT AND SUPPORT YOUR VEHICLE. NEVER WORK UNDER A VEHICLE SUPPORTED BY A FLOOR OR BUMPER JACK.

COMPATIBILITY INFORMATION:

These headers were specifically designed to be installed with HOOKER[™] LS swap engine and transmission mounting components and exhaust systems for this same application. Attempts to install these headers with any other type or combination of engine and transmission mounting components may cause them to not provide their intended ground or vehicle component clearances, or compatibility with the related HOOKER[™] exhaust systems.

These headers are fully compatible for use with the stock A/C evaporator case, power brake booster and OE LS spark plug wires.

INSTALLATION:

- 1. Disconnect the negative cable from the vehicle battery, if connected.
- 2. Remove spark plugs wires from the spark plugs then remove the spark plugs from the engine.
- 3. Remove the engine oil dipstick tube.
- 4. Remove any transmission linkage present between the transmission and steering column.
- 5. Using an automotive lift or floor jack, lift the entire vehicle or front of the vehicle a minimum of 12" to 15" off the ground.
- 6. Starting with the driver's side header assembly, maneuver it into place between the engine and vehicle frame through the bottom of the vehicle and attach it to the engine using 1 supplied gasket and 1 header flange bolt.
- 7. Maneuver the passenger's side header into position between the engine and vehicle frame through the bottom of the vehicle and attach it to the engine using the remaining supplied gasket and 1 header flange bolt.
- 8. Complete installation of remaining header flange bolts from the top of the engine compartment and tighten all bolts.
- 9. Reinstall engine oil dipstick tube, spark plugs and spark plug wires.
- 10. Install O2 sensors into bungs if using; install O2 plugs (user supplied) if not using O2 sensors.
- 11. Reconnect battery if previously disconnected.

LIMITATION OF LIABILITY - DISCLAIMER:

The regulation of emissions production, noise levels, and safety standards is undertaken by the federal government, each of the fifty state legislatures, and by many local municipalities, towns, and counties.

HOOKER[™] makes no warranties of merchantability, of fitness for particular purpose, or that its products are approved for general use, or that its products comply with laws, regulations, or ordinances in the state where they may be sold to the ultimate purchaser, the consumer.

Unless expressly stated to the contrary in the catalog, instruction sheet; or price list, the entire risk as to the conformity of any company product in any such state and as to repair should the product prove to be defective or non-conforming, is on the retail purchaser, the buyer, the ultimate consumer, of such product and it is not upon the seller, distributor, or manufacturer.

In this connection, the retail purchaser, the buyer, the ultimate consumer assumes the burden of the entire cost of any and all necessary service, alterations, or repair.

THE FOREGOING STATEMENT LIMITS THE LIABILITY OF THE MANUFACTURER.

California vehicle code, sections 27156 and 38391, prohibits the advertising, offering for sale, or installation of any device, which modifies a vehicle's emission control system, unless exempted, unless otherwise noted. HOOKER[™] Headers that have not received an Executive Order (E.O.) exemption from these code sections are not legal for sale or use in California on vehicles originally equipped with catalytic converters, except for racing vehicles, which may never be driven upon a highway. Check with your local authorities to determine if these headers are legal for use in your particular area.

Technical Service: 1-866-464-6553 Phone: 1-270-781-9741 Fax: 1-270-781-9772 For online help, please refer to the Tech Service section of our website: <u>www.holley.com</u>

© 2015 Hooker Headers, Inc. All rights reserved.

199R10731 Date: 1-12-15