Push-In Style Turn Lever Instructions

This switch is a direct replacement for your factory switch. It will mount in the exact same way.

To remove the original lever, make sure it is in the "OFF" position, then tug sharply straight out.



610 S. Maumee St. Tecumseh, MI 49286 PH: 517-424-0577 FAX: 517-424-7293 Instruction #: 8000010102 REV 01/13