


Installation Instructions for 81145

Air Belt Sander

0.6 HP



NO	PART NO	DESCRIPTION	Q'TY
1	ST70601	AIR INLET	1
2	ST70602	EXHAUST COVER	1
3	ST70603	SILENCER (60L)	1
4	ST70604	SPRING	1
5	ST288315	VALVE	1
6	ST288316	WASHER	1
7	ST70607	HOUSING	1
8	ST70608AS	REGULATOR SET	1
9	ST70612AS	VALVE STEM SET	1
10	2HG-16A	SNAP RING (STW-9)	1
11	ST-70614	SAFTY THROTTLE LEVER	1
12	12012.1	SPRING PIN (3x24L)	1
13	ST70616	CAP	1
14	90443	O-RING (AS029)	1
15	22536A	BEARING (626ZZ)	1
16	ST70619	REAR PLATE	1
17	ST70620AS	CYLINDER SET	1
18	ST70622	ROTOR BLADE	6
19	ST70623	ROTOR	1
20	ST70624	KEY	1
21	ST25125	BEARING SPACER	1
22	ST70625	FRONT PLATE	1

NO	PART NO	DESCRIPTION	Q'TY
23	70048A	BEARING (6000ZZ)	1
24	ST70664	DUSTPROOF WASHER	1
25	ST70727	DRIVE PULLEY	1
26	ST70628	WASHER (6.4x11.5x1.6t)	1
27	ST70629	NUT (M6)	1
28	ST187550	TRIGGER	1
29	ST187551	BUSHING	1
30	ST70632	GUARD HUB	1
31	BT246652-4	SCREW	1
32	2HG4-32	SCREW (M5x0.8Px12L)	1
33	ST70748BAS	TENSION BAR SET	1
34	ST70740	SHOE	1
35	80528	SCREW (M5x0.8Px6L)	1
36	ST70634	GUARD COVER	1
37	ST70753AS	IDLE PULLEY SET	1
38	ST70754	SCREW (M3x0.5P)	1
39	ST70757-40#	SANDING BELT (40#)	1
39	ST70757-60#	SANDING BELT (60#)	1
39	ST70757-80#	SANDING BELT (80#)	1
40	ST70659	HEX (2mm)	1
41	23039	HEX (3mm)	1



1-800-345-4545 jeps.com