



# OILING INSTRUCTIONS

## K&N Airforce Pre-Cleaner

This K&N Airforce Pre-Cleaner must be oiled before using. Use K&N Filter Oil.

### INSTRUCTIONS:

#### OILING:

1. Saturate the K&N Airforce Pre-Cleaner with K&N Filter Oil.
2. Massage until it is fully covered.
3. Squeeze, do not wring the excess oil from the K&N Airforce Pre-Cleaner.
4. Install the K&N Airforce Pre-Cleaner on the K&N Air Filter per the installation instructions.

#### CLEANING:

1. Remove the K&N Airforce Pre-Cleaner from the K&N Air Filter.
2. Clean with K&N Cleaner or soap and water.
3. Air dry before RE-OILING.