




## LOW OIL PRESSURE WARNING LIGHT P/N 49500

### INSTALLATION INSTRUCTIONS


Install components as shown in diagram.  
Sending unit is factory set at 15 PSI. If a setting other than 15 PSI is desired, this Sending unit is easily adjustable by removing rubber cap and adjusting set screw with Allen wrench.



## LOW OIL PRESSURE WARNING LIGHT P/N 49500

### INSTALLATION INSTRUCTIONS

Install components as shown in diagram.  
Sending unit is factory set at 15 PSI. If a setting other than 15 PSI is desired, this Sending unit is easily adjustable by removing rubber cap and adjusting set screw with Allen wrench.



*For Technical Assistance, Call Moroso's Tech Line at  
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time*

MOROSO PERFORMANCE PRODUCTS, INC  
80 CARTER DR • GUILFORD, CT 06437  
Phone: (203) 453-6571 • Fax: (203) 453-6906

Rev. D  
091511

Visit Us At [www.moroso.com](http://www.moroso.com)

49500INST

*For Technical Assistance, Call Moroso's Tech Line at  
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time*

MOROSO PERFORMANCE PRODUCTS, INC  
80 CARTER DR • GUILFORD, CT 06437  
Phone: (203) 453-6571 • Fax: (203) 453-6906

Rev. D  
091511

Visit Us At [www.moroso.com](http://www.moroso.com)

49500INST