Installation Instructions for 511030 to 511036 Stainless Steel Overflow Tanks

Installation Instructions:

Mount the overflow tank so that the top of the overflow tank is level with the top of the radiator core.

The overflow nipple on the radiator should be plumbed to the **<u>SHORT</u>** tube on the bottom of the overflow tank.

The **LONG** tube on the bottom of the overflow tank is the vent.



1-800-345-4545 jegs.com