Installation Instructions for 60354 Replacement Gasket Set

for 555-60350 & 555-60352 Transmission Coolers

Instructions:

- 1. Remove transmission cooler end caps by removing the Four (4) screws from each end.
- 2. Clean / flush entire unit.
- 3. Clean screw threads and gasket surfaces.
- 4. Apply thread sealant to screw threads and reassemble transmission cooler.



1-800-345-4545 jegs.com