

MSD[®] IGNITION INSTALLATION INSTRUCTIONS

MSD 10-Plus Ignition Coil PN 8208

Important: Read the instructions before attempting the installation.

Parts Included:

1 – MSD 10-Plus Coil, PN 8208

1 – Coil Harness

3 – Vibration Mounts and Hardware

WARNING: During installation, disconnect the battery cables. When disconnecting, always remove the Negative cable first and install it last.

The 10-Plus Coil, PN 8208, is the only coil that can be used with this ignition system. It is specifically designed to handle the CD and Inductive spark characteristics of the 10-Plus.

The MSD 10-Plus Ignition system uses MSD's patented Stacker Ignition technology to combine the best offerings of a Capacitive Discharge ignition with the best features of an Inductive ignition. The CD circuits of the ignition produce very high voltage that is responsible for ionizing the spark plug gap while the Inductive side produces incredible current for a high level of sustained spark across the gap.

Note: This Coil, PN 8208, cannot be used or mixed with any component from the original MSD 10 Ignition system, PN 7500.

WARNING: High voltage is present on the coil terminals. **DO NOT** touch the coil terminals while the engine is cranking or running.




Figure 1 Wiring to a Magnetic Pickup.



This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and extend across the width of the page. There are no margins, text, or other markings on the paper.

When returning the unit for repair, leave all wires at the length in which you have them installed. Be sure to include a detailed account of any problems experienced, and what components and accessories are installed on the vehicle. The repaired unit will be returned as soon as possible using Ground shipping methods (ground shipping is covered by warranty). For more information, call MSD Ignition at (915) 855-7123. MSD technicians are available from 7:00 a.m. to 6:00 p.m. Monday - Friday (mountain time).

*Intended normal use means that this item is being used as was originally intended and for the original application as sold by MSD Ignition. Any modifications to this item or if it is used on an application other than what MSD Ignition markets the product, the warranty will be void. It is the sole responsibility of the customer to determine that this item will work for the application they are intending. MSD Ignition will accept no liability for custom applications.