

2-3/4" After Cat X-Pipe

Part #1460



Special Tools

Required:

- No special tools required

Install Time:

Approximately
1 Hour

Difficulty:

2 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

STEP 1

- Disconnect the negative battery terminal. Raise the vehicle up and safely support it.

STEP 2

- Loosen barrel style clamps at the rear of the stock H-Pipe section. Support rear exhaust pipe sections behind H-pipe sections. Loosen the clamps at the front of the H-Pipe section where it connects to the catalytic converter pipes. Now remove the stock H-Pipe Section.

STEP 3

- With a flat head screwdriver, lift the locking tab on the barrel clamps and remove from the H-Pipe. Slide the barrel clamps back onto the stock exhaust pipes.

STEP 4

- Lift the BBK X-Pipe section into place and connect to the barrel clamps first.

STEP 5

- Position the front of the BBK X-Pipe to make the connection to the catalytic converter pipes. You will have to unscrew the clamps all the way out. Position the front of the BBK X-Pipe up against the round end of the catalytic converter pipes to make the connection. Position the clamps in place and tighten the clamps enough to hold.

STEP 6

- Check the position of the exhaust system and make any adjustments up or down. When satisfied with the exhaust system placement, tighten the barrel style clamps.

STEP 7

- Now tighten all the clamps starting from the front of the car.

STEP 8

- Reconnect the negative battery terminal and start the engine to check for leaks. Sometimes the connection at the catalytic converter pipes can be a bit tricky to get sealed. If you are having trouble with a leak there, just barely loosen the barrel style clamps and loosen the front clamps again to pull the X-Pipe up to the converter pipes, and then re-tighten the front clamps first, then the rear barrel style clamps.



Join our Facebook page
www.facebook.com/bbkperformance



Follow us on Twitter
[@bbkperformance](https://twitter.com/bbkperformance)



Check us out on Youtube
www.youtube.com/bbkperformance

WWW.BBKPERFORMANCE.COM

For any questions, email us:

tech@bbkperformance.com

installation instructions

1

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

INS-159