



70mm Throttle Body

Part # 1723



Special Tools

Required:

- No special tools required

Install Time:

Approximately
45 Mins

Difficulty:

1 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

STEP 1

- Disconnect the negative battery terminal.

STEP 2

- Remove the air duct from the throttle body.

STEP 3

- Disconnect all hoses, electrical connectors, etc. from the throttle body.

STEP 4

- Disconnect the throttle cable and any other cables that are attached to the throttle linkage.

STEP 5

- Unbolt the throttle body from the intake manifold and remove it from the vehicle carefully making sure not to damage the factory re-usable

STEP 6

- Transfer the TPS and IAC valve from the stock throttle body to the BBK Throttle Body using the factory hardware and gasket.

STEP 7

- Installation is the reverse of disassembly from the vehicle. Make sure the gasket is seated properly on the intake and is free of any debris.
NOTE!!! Take great care in re-installing the stock mounting hardware into the manifold, the screws self-tap into the plastic and must follow the same thread upon installation. If over tightened the plastic will strip, damaging the plastic intake manifold.

STEP 8

- After re-installing the negative battery terminal, start the vehicle using only the key (No accelerator) and allow to idle until up to full coolant operating temperature; this will allow the computer to establish the appropriate idle speed for the new throttle body.



Join our Facebook page
www.facebook.com/bbkperformance



Follow us on Twitter
[@bbkperformance](https://twitter.com/bbkperformance)



Check us out on Youtube
www.youtube.com/bbkperformance

WWW.BBKPERFORMANCE.COM

For any questions, email us:

tech@bbkperformance.com

installation instructions

1

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

INS-086