

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 39489**

2009 Ford Mustang GT 4.6L - Stainless Steel Dual Exhaust System



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the original mufflers by loosening the muffler pipe clamps and the muffler rod hanger bracket assemblies from the vehicle underbody. Remove the original front pipes by loosening the inlet clamps.
2. Install RH front intermediate pipe **52450** and LH front intermediate pipe **52449** along with RH rear intermediate pipe **54690** and LH rear intermediate pipe **54689**. Do not fully tighten the original inlet clamps to front pipes at this time Please see system diagram.
3. Remove the rod hanger bracket assemblies from the original mufflers and install these on the DynoMax Bullet mufflers: **17575 (RH)** and **17576 (LH)**. Be sure to note the correct location and installation position of each hanger bracket assembly.

4. Install DynoMax Bullet mufflers by inserting the muffler inlet pipes onto the rear intermediate pipes and bolting the rod hanger bracket assemblies to the vehicle underbody. Use the DynoMax band clamps supplied to the clamp the Ultra Flo Bullet mufflers to the outlet of the front pipes.
5. Beginning at inlet end, align the system and tighten all the clamps.
6. Start the vehicle and check for exhaust system leaks. Retighten and position as required

SEE THE FULL SYSTEM DIAGRAM ON THE BACK PAGE.

KIT CONTAINS:

- (1) 17575 RH BULLET MUFFLER
- (1) 17576 LH BULLET MUFFLER
- (1) 52450 RH FRONT INT. PIPE
- (1) 52449 LH FRONT INT. PIPE
- (1) 54690 RH REAR INT. PIPE
- (1) 54689 LH REAR INT. PIPE
- (4) 3" BAND CLAMPS
- (1) 709589 INSTRUCTION SHEET

39489 SYSTEM DIAGRAM

