



SBL-MAD Assembly

Assemble and install as shown; tighten until bushing diameter is same as washer diameter.



SBL-MAD Assembly

Assemble and install as shown; tighten until bushing diameter is same as washer diameter.

