

Installation Instructions for 15094
Jr. Dragster Fuel Pump Rebuild Kit
For Mikuni Medium Volume Single Outlet Fuel Pump

NOTES:

1. Do not use gasket sealer during assembly.
2. Use hose clamps on all hose connections.

Screw with Washer

Tightening Torque:

$20 \pm 5 \text{ kg} \cdot \text{cm}$

$30 \pm 6 \text{ lb} \cdot \text{in}$

$1.9 \pm 0.5 \text{ N} \cdot \text{m}$

Cover

555-15092

(not included)

Gasket
(fiber)

Diaphragm
(clear)

Membrane
(thin, black rubber)

Bottom Body Assembly

555-15092

(not included)

