


User Guide

Bluetooth Unit Interface

(Classic 630 Series Radios)




Installation

WARNING

Ensure that your radio is turned off before installation

- Plug the BLUKIT into the CD changer input on the back of your CD ready Classic 630 radio. If you are using a CD changer plug it into the 8 pin plug on the Bluetooth Unit.
- Secure the box behind your dash.
- The Bluetooth button and microphone need to be mounted in a location that is accessible.
 - As an example the microphone may be mounted on the sun visor and the wire run down the A-pillar to the Bluetooth button.
- The Bluetooth button must be accessible while driving. It is used to answer and hang up your cell phone calls.
- You may have to try different locations for the microphone to get the best sound quality.

Wiring Diagram



Operation

OVERVIEW

- To pair a Bluetooth device to your Classic 630 radio you must first connect the Bluetooth Unit interface module.
- When connected to a CD ready head unit the Bluetooth Unit supports the HFP (Hands-Free Profile), and the A2DP (Advanced Audio Distribution Profile).

PREPARATION

- To use a mobile device with this head unit, it must be paired and connected. Please make sure that Bluetooth is activated on your mobile device before you begin the pairing process.
- Refer to the owner's manual of your mobile device for more details.

BLUETOOTH PAIRING

- To pair a Bluetooth enabled mobile phone to your head unit, put the head unit in CD mode
- If the Bluetooth Unit is connected properly the green Bluetooth button will be flashing.
- Complete the pairing in the Bluetooth menu of your mobile device by searching for new devices.

- Please refer to your mobile device instructions for further information on Bluetooth pairing and connections. The Bluetooth light will illuminate solid when connected.

PAIRING INFO

DEVICE NAME: CHB011

PASSWORD: 0000

Not all devices require a password

COMPATIBILITY

- Due to the differences in Bluetooth technology, some mobile devices may be incompatible or function improperly when used with the Bluetooth Unit.

Radio Modes

SWITCHING BETWEEN RADIO MODES

- To listen to your Bluetooth enabled device the radio must be in CD mode.
- If using a CD changer and you wish to switch between CD and Bluetooth follow the procedure for your model of radio.
 - **630-Series** to switch between Bluetooth and CD press the CD/Mode button 5 times. Pressing the CD button 5 time again will switch back to the previous mode.

ANSWERING THE PHONE

- If your phone rings while in Bluetooth mode you will hear it through your stereo speakers.
- Just press the Bluetooth button to answer.
- When done with your call press again and your music will return.
- If you are in an other mode when the phone rings put your radio into Bluetooth mode (CD mode) and press the Bluetooth button.

MUSIC CONTROL

- If your phone is capable, you can advance the song you are listening to by using the Track Up button on your radio.

BLUETOOTH POWER OFF

- Once you turn the radio or ignition off, the Bluetooth Unit will delay off in 20 seconds.
- When you turn power back on, your Bluetooth should reconnect automatically on most phones.