


Installation Instructions for 79011 Transmission Jack Fuel Tank Adapter



PART	DESCRIPTION	QTY
1	Wing NUT M14	2
2	Flat Washer ϕ 14	2
3	Wing NUT M6	3
4	Flat Washer ϕ 6	3
5	Ground Screw M6	1
6	Lock Rod	1
7	Wing NUT M8	8
8	Ground Screw M14	2
9	Ground Screw M8X20	1

PART	DESCRIPTION	QTY
10	Adapter Plat	1
11	Locking Knod	4
12	Base Assembly	1
13	Arm Assembly	4
14	Ground Screw M8	8
15	Height Adjustment tube	4
16	Support Pad Assembly	4