


Dual Laser

GARAGE LASER PARK


Included Parts

- 1- Dual Garage Laser Park with Mounting Bracket
 - 1- AC Adapter (120V AC input, 6V DC output)
 - 3- Screws
 - 2- Double-Stick Tape
1. Find a suitable mounting location close to an electrical outlet (typically the outlet used to power your garage door opener). The mounting location should be inaccessible to children or pets. Detach the white mounting bracket from the main unit. Attach the mounting bracket to the ceiling or wall as shown with the 3 screws or double-stick tape. Be sure the bracket is oriented correctly; if you are mounting it on the ceiling, the arrow shown below on the mounting bracket should point towards the garage door; if you are mounting it on the wall, it should point towards the ground.


CAUTION: Do NOT use double-stick tape to mount the unit on a ceiling. Mount securely with screws.



2. The batteries are only a backup if power is interrupted and they will not last for more than a few days. To install the backup batteries, remove the battery compartment door and install 3 AA 1.5V batteries, matching the correct +/- polarity as shown in the compartment.
3. Slide the main unit into the black mounting bracket as shown.



4. Plug in the AC adapter.
5. Park your cars in the desired positions. Adjust the laser beams so that they shine on a prominent feature on each car. Good choices include a spot on the dashboard or the space between the hood and the windshield. Remember, you must be able to see the spot from the driver's seat while parking the car. Do not allow the laser beams to reflect off a shiny surface and into your eyes.



6. When either of your cars first enters the garage, the motion detector will turn on both lasers. Drive forward until the laser beam for your vehicle hits your pre-determined spot indicating that you are parked in the correct position. Both lasers will turn off automatically after you are parked.


Troubleshooting

The Garage Laser Park lasers may sometimes appear to stay on permanently and never turn off. The Garage Laser Park turns on each time it senses motion. It can be triggered by any movement in the garage such as a door opening, an animal moving, or a car entering the garage. As a result, a homeowner may think that the laser never turns off. In these cases what is usually happening is that each time the homeowner looks in the garage, the laser is triggered when the door is opened. If you believe that the laser is not turning off, please check it in a way that the motion sensor will not be triggered.

Garage Parking Guide

Dual Laser

GARAGE LASER PARK



AVOID EXPOSURE, LASER
RADIATION IS EMITTED FROM
THE APERTURE.

- Laser devices can be harmful if used improperly.
- Do not aim into eyes.
- Do not look into aperture while laser is on.
- Install in a location inaccessible to children or pets.
- No user-serviceable parts. Do not open product case.
- Caution: Use of controls or adjustments or performance procedures other than those specified herein may result in hazardous radiation exposure.

Indoor Use Only

90 DAY LIMITED WARRANTY

MAXSA Innovations, LLC warrants to the original consumer/purchaser that this product shall be free of defects in material and workmanship under normal use and circumstances for a period of ninety (90) days from the date of original purchase for use. When the original consumer/purchaser returns the product pre-paid (consumer pays return shipping) to MAXSA Innovations, LLC, 8412 Cathedral Forest Dr; Fairfax Station, VA 22039; USA within the warranty period, and if the product is defective, MAXSA Innovations, LLC will at its option repair or replace such. This warranty shall constitute the sole liability of MAXSA Innovations, LLC concerning the product. MAXSA Innovations, LLC expressly disclaims all other warranties INCLUDING, WITHOUT LIMITATION, THE WARRANTIES OF MERCHANT ABILITY AND FITNESS FOR A PARTICULAR PURPOSE. NO PERSON, FIRM, OR CORPORATION IS AUTHORIZED TO ASSUME FOR MAXSA Innovations, LLC ANY OTHER LIABILITY IN CONNECTION WITH THE SALE AND USE OF THE PRODUCT. MAXSA Innovations, LLC and agents and distributors will bear no liability whatsoever for incidental or consequential damages or charges of any kind. Some states do not allow the reclusion or limitation of incidental or consequential damages, so the above disclaimer regarding incidental or consequential damages may not apply to you. This warranty is void if the product has been damaged or tampered with or if the product or any such parts have been opened. In all cases of damage during shipment, a claim must be filed with the shipping carrier and not with MAXSA Innovations, LLC. This warranty gives you specific legal rights; you may also have other rights which vary from state to state.

OUT OF WARRANTY REPAIRS

If the warranty period has expired, MAXSA Innovations, LLC will at its option either (1) replace this product with a functionally similar (but not necessarily identical) refurbished product or (2) repair the original product and return it to the original consumer/purchaser after payment of repair/replacement charges has been received.

GARAGE LASER PARK

Pièces incluses:


- 1- Laser de stationnement pour votre garage (unité centrale) avec accessoires d'installation
- 1- Adaptateur AC (120 Volts AC d'entrée, 6 Volts DC de sortie)
- 2- Vis
- 3- Collant double face

Détacher le support noir de fixation de l'unité centrale.


Trouver l'endroit idéal et attacher le support de fixation au plafond ou au mur (voir ci-dessous) avec les 3 vis ou le collant double face.

ATTENTION: Ne pas utiliser le collant double face si vous installez votre unité centrale au plafond. Sécuriser la fixation avec les vis fournies.

Plafond ou Mur




2. Faire glisser l'unité centrale sur le support noir de fixation comme indiqué ci-dessous.



3. Monter l'unité près d'une prise électrique (en général près de celle utilisée pour l'ouverture électrique de votre porte de garage). Brancher l'adaptateur AC. La pile sert juste de secours au cas où il y a une coupure de courant et ne durera que quelques jours. Pour installer les piles de secours, enlevez la portière du compartiment de piles et insérez 3 piles AA 1.5V, en respectant la polarité +/- telle qu'indiquée dans le compartiment.

4. Garer vos voitures à l'emplacement désiré. Ajuster les rayons du laser afin qu'ils illuminent une bonne partie de chaque voiture. Vous chercherez à ce que le laser éclaire un endroit du tableau de bord ou entre le toit et le pare-brise. N'oubliez pas, vous devez pouvoir voir cet endroit du siège du conducteur lorsque vous vous garer.



5. Lorsqu'une ou l'autre de vos voitures entre dans le garage en premier, le détecteur de mouvement allume les deux lasers. Avancez jusqu'à ce que le laser que vous avez ajusté pour votre véhicule éclaire le point de repère prédéterminé, indiquant que vous êtes stationné dans la bonne position. Les deux lasers s'éteindront automatiquement après que vous aurez stationné.

Dépannage

Les lasers du Garage Laser Park peuvent parfois sembler rester toujours allumés et ne jamais s'éteindre. Le Garage Laser Park s'allume à chaque fois qu'il détecte un mouvement. Le mouvement peut résulter de n'importe quel déplacement dans le garage tel que l'ouverture d'une porte, le mouvement d'un animal, ou l'approche d'un véhicule dans le garage. Ainsi, un propriétaire peut avoir l'impression que le laser ne s'éteint jamais. Dans ces cas, il s'avère souvent qu'à chaque fois que le propriétaire vérifie dans le garage, il actionne le laser en ouvrant une porte. Si vous croyez que le laser ne s'éteint pas, veuillez le vérifier d'une façon qui ne déclenchera pas le détecteur de mouvement.

GARAGE LASER PARK



EVITER A L'EXPOSITION, LA
RADIATION DU LASER EST
EMISE PAR L'ORIFICE.

Ce produit est en règle
avec le 21 CFR
chapitre 1, section
1040.10 et 1040.11

- Les appareils de laser peuvent être dangereux si utilisés incorrectement.
- Ne pas diriger vers les yeux.
- Ne pas regarder vers l'orifice lorsque le laser est en fonctionnement.

Utilisation d'intérieur seulement.

90 DAY LIMITED WARRANTY

MAXSA Innovations, LLC garantit pièces et main d'œuvre au consommateur / acheteur originel dans le cas d'utilisation normale du produit pour une durée de 90 jours de la date d'achat du produit. Lorsque le consommateur / acheteur originel renvoie le produit payé antérieurement à MAXSA Innovations, LLC, 8412 Cathedral Forest Dr; Fairfax Station, VA 22039; USA pendant la période de garantie, et si le produit est défectueux, MAXSA Innovations, LLC prendra la décision de réparer ou remplacer le produit.

Cette garantie est la seule responsabilité de MAXSA Innovations, LLC envers ce produit. MAXSA Innovations, LLC nie expressément tout autre garantie incluant, sans limitation, les garanties de valeur commerciale et de convenance pour un but particulier. Aucune personne, entreprise ou société n'est autorisée à endosser pour MAXSA Innovations, LLC tout autre responsabilité en rapport avec l'achat et l'utilisation de ce produit. MAXSA Innovations, LLC, représentants et distributeurs rejeteront toute responsabilité en cas de dommages-intérêts accessoires ou dommages-intérêts indirects ou d'accusation de tout genre.

Certains Etats n'acceptent pas l'exclusion ou limitation de dommages-intérêts accessoires ou dommages-intérêts indirects, donc le démenti ci-dessus couvrant les dommages-intérêts accessoires ou dommages-intérêts indirects ne vous affecte peut-être pas.

Cette garantie est annulée si le produit a été endommagé ou altéré, ou si le produit ou les pièces ont été ouverts. En toute circonstance de dommage pendant le transport, une demande d'indemnité doit se faire avec la compagnie de transport et non MAXSA Innovations, LLC.

Cette garantie vous donne des droits légaux spécifiques, vous faites peut-être l'objet d'autres droits ce qui varient d'un Etat à un autre.

Réparations hors période de garantie

Si la période de garantie a expiré, MAXSA Innovations, LLC prendra la décision de remplacer le produit avec un produit remis à neuf de fonctionnalité similaire (mais pas forcément identique) ou bien de réparer le produit original et de le renvoyer au consommateur / acheteur originel après avoir reçu payment des frais de réparation / remplacement.
