




Oil Separator/Breather

P/N 68786, 68787

Refer to the assembly drawing for installation procedure

1. Install the Mounting Stud through the inside of the Valve Cover. The recommended sized hole for the Mounting Stud is 1-1/8" to 1-1/4".
2. On the outside, install the Gasket, Washer and one of the Locknuts. Tighten the Locknut to compress the Gasket so that it conforms to the Valve Cover. (Do not over-tighten)
3. Install the second Locknut and then the Breather. Thread each piece down until they contact the first Locknut and tighten the second Locknut against the bottom of the Breather.



*For Technical Assistance, call Moroso's Tech Line at
(203) 458-0542, 8:30am-5:00pm Eastern Time*

MOROSO PERFORMANCE PRODUCTS, INC
80 Carter Drive • Guilford, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com

68786INST

Rev. B
041312




Oil Separator/Breather

P/N 68786, 68787

Refer to the assembly drawing for installation procedure

1. Install the Mounting Stud through the inside of the Valve Cover. The recommended sized hole for the Mounting Stud is 1-1/8" to 1-1/4".
2. On the outside, install the Gasket, Washer and one of the Locknuts. Tighten the Locknut to compress the Gasket so that it conforms to the Valve Cover. (Do not over-tighten)
3. Install the second Locknut and then the Breather. Thread each piece down until they contact the first Locknut and tighten the second Locknut against the bottom of the Breather.



*For Technical Assistance, call Moroso's Tech Line at
(203) 458-0542, 8:30am-5:00pm Eastern Time*

MOROSO PERFORMANCE PRODUCTS, INC
80 Carter Drive • Guilford, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com

68786INST

Rev. B
041312