



PART #85280
REAR END & WATER FILL CAP
INSTALLATION

Weld to rear-end housing in line with the ring gear where it will provide an easy fill location and also allow inspection of the ring gear.

Where used as a water filler it may be welded to a steel water fill neck plate to provide a compact water filler.

Other Uses: This cap may be used on all types of steel tanks where a non-vented cap is desired.

*For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time*

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com



PART # 85280
REAR END & WATER FILL CAP
INSTALLATION

Weld to rear-end housing in line with the ring gear where it will provide an easy fill location and also allow inspection of the ring gear.

Where used as a water filler it may be welded to a steel water fill neck plate to provide a compact water filler.

Other Uses: This cap may be used on all types of steel tanks where a non-vented cap is desired.

*For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time*

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com



PART # 85280
REAR END & WATER FILL CAP
INSTALLATION

Weld to rear-end housing in line with the ring gear where it will provide an easy fill location and also allow inspection of the ring gear.

Where used as a water filler it may be welded to a steel water fill neck plate to provide a compact water filler.

Other Uses: This cap may be used on all types of steel tanks where a non-vented cap is desired.

*For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time*

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com



PART #85280
REAR END & WATER FILL CAP
INSTALLATION

Weld to rear-end housing in line with the ring gear where it will provide an easy fill location and also allow inspection of the ring gear.

Where used as a water filler it may be welded to a steel water fill neck plate to provide a compact water filler.

Other Uses: This cap may be used on all types of steel tanks where a non-vented cap is desired.

*For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time*

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com



PART #85280
REAR END & WATER FILL CAP
INSTALLATION

Weld to rear-end housing in line with the ring gear where it will provide an easy fill location and also allow inspection of the ring gear.

Where used as a water filler it may be welded to a steel water fill neck plate to provide a compact water filler.

Other Uses: This cap may be used on all types of steel tanks where a non-vented cap is desired.

*For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time*

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com



PART # 85280
REAR END & WATER FILL CAP
INSTALLATION

Weld to rear-end housing in line with the ring gear where it will provide an easy fill location and also allow inspection of the ring gear.

Where used as a water filler it may be welded to a steel water fill neck plate to provide a compact water filler.

Other Uses: This cap may be used on all types of steel tanks where a non-vented cap is desired.

*For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time*

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com