


ALUMINUM POWERGLIDE

Pressure Regulator Valve

Part No.

28999-03

1 Pressure Regulator Valve



Disassembly Instructions:

1. Remove the OEM pressure regulator valve.
2. Remove the spring seat clip from the valve and retain.
3. Discard the OEM pressure regulator valve.

Installation / Assembly Steps:

1. Press the OEM spring seat clip onto the stem of the replacement pressure regulator valve.
2. Slide the replacement pressure regulator valve into the bottom of the valve body bore.
3. Return OEM spring, spring cup and boost valve assembly to the bore, and retain with the OEM retaining clip.