

VOLANT AIR INTAKE SYSTEMS
 PART NO.: 16957
 INSTALLATION INSTRUCTIONS
 WWW.VOLANTPERFORMANCE.COM
 TECH SUPPORT: (909) 476-7225

16957 PARTS LIST					
1	VOLANT FILTER BOX	1	1/4"-20 BOLT	1	5/8" X 18" BREATHER HOSE
1	VOLANT FILTER BOX LID	1	3/8" BOLT	1	1/2" X 14" VINYL TRIM
1	VOLANT AIR DUCT	1	3/8" WASHER	1	1/2" X 22" VINYL TRIM
1	RAM FILTER W/CLAMP	1	1/4" WASHER	1	VOLANT BRACKET
5	1/4"-20 TRUSS HEAD SCREWS	1	1/4" LOCK WASHER	1	1/2" RUBBER GROMMET
5	1/4" RUBBER WASHERS	1	3/8" EXTRUDED U NUT	1	5/8" RUBBER GROMMET
2	#056 CLAMPS	1	3 1/2" X 3" SLEEVE	1	5/8" ELBOW FITTING

(5) 1/4"-20 TRUSS HEAD SCREWS
 (5) 1/4" RUBBER WASHERS
 FILTER BOX LID

TOP VIEW

VOLANT FILTER
 BOX LID

SIDE VIEW

NOTE: ATTACH THE
 STOCK BOLT TO
 THE RADIATOR CORE
 SUPPORT

STOCK BOLT

VOLANT BRACKET
 1/4" WASHER
 1/4" LOCK WASHER
 1/4"-20 BOLT

1/2" X 22"
 VINYL TRIM
 W/SPONGE

VOLANT
 FILTER BOX

1/2" X 14"
 VINYL TRIM
 W/SPONGE

3/8" BOLT
 3/8" WASHER
 FILTER BOX LID

3/8"
 EXTRUDED
 U NUT

5/8" ELBOW
 FITTING 5/8" X 18"
 BREATHER HOSE

5/8" RUBBER
 GROMMET

1/2" RUBBER GROMMET

VOLANT
 AIR DUCT

#056
 CLAMP

3 1/2" X 3"
 SLEEVE

#056
 CLAMP

THRITTLE
 BODY

VOLANT BRACKET
 1/4" WASHER
 1/4" LOCK WASHER
 1/4"-20 BOLT

