

Kit Includes:

1. Bellhousing spacer
2. Hyd release bearing spacer
3. Pilot bearing
4. Transmission dowels x 2
5. Transmission to bellhousing bolts x 7
6. Hyd release bearing bolts x 2