PUTCO™

Interior Dome Light Installation Instructions

1. Gently remove your dome light covers

2. Remove the bulbs from the sockets.

3. Install the new Pure LED lights by placing the metal rings into the sockets.

4. Once installed carefully replace the cover on your new dome lights!

© PUTCO