

# Long Tube Headers & Matching Y-Pipe

Part # 1694,16940



Special Tools  
Required:

- Soldering Iron
- Solder

Install Time:

Approximately  
2 Hours

Difficulty:

3 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

### STEP 1

- Lift the vehicle as high as possible then disconnect the negative battery terminal.

### STEP 2

- Unplug the oxygen sensors from their wire harness connections.

### STEP 3

- Unbolt the Y-Pipe exhaust hanger from the transmission if applicable.

### STEP 4

- Loosen the clamp that connects the Y-Pipe outlet to the tail pipe section.

### STEP 5

- Remove the cross brace from under the Y-Pipe if applicable.

### STEP 6

- Unbolt the Y-Pipe from the catalytic converters and remove it from the vehicle.

### STEP 7



- Remove the nuts that connect the catalytic converters to the exhaust manifolds, and then remove the converters from the vehicle.

### STEP 8

- Unbolt the EGR connections that attach to the factory exhaust manifolds. ***NOTE!!! There are no EGR connections on the BBK Headers. You may block off or remove the existing tubes at this time if you have not already done so.***

### STEP 9

- Remove the spark plug wires to avoid damaging them during header installation.



Join our Facebook page  
[www.facebook.com/bbkperformance](http://www.facebook.com/bbkperformance)



Follow us on Twitter  
[@bbkperformance](https://twitter.com/bbkperformance)



Check us out on Youtube  
[www.youtube.com/bbkperformance](http://www.youtube.com/bbkperformance)

GO TO NEXT PAGE

[WWW.BBKPERFORMANCE.COM](http://WWW.BBKPERFORMANCE.COM)

For any questions, email us:

[tech@bbkperformance.com](mailto:tech@bbkperformance.com)

installation instructions

1

**IMPORTANT:** All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

INS-114

# Long Tube Headers & Matching Y-Pipe

Part # 1694,16940



### STEP 10

- Pull out the dipstick, unbolt the dipstick tube, and remove it from the car by pulling the tube up and out of the engine block.

### STEP 11



- Remove the bolts that attach the steering shaft to the steering rack and firewall steering column yoke.

### STEP 12

- Unbolt and remove the stock exhaust manifolds and gaskets. Transfer all the oxygen sensors to the BBK Headers and Y-Pipe. ***NOTE!!! Be sure to add a small amount of anti-seize to the top thread of each oxygen sensor using the supplied anti-seize packet. As you thread the oxygen sensor back into the part the anti-seize will spread evenly throughout the threads.***

### STEP 13

- Install the BBK Headers and supplied gaskets using the factory header bolts. Thread the supplied collector studs into the headers by hand.

### STEP 14

- Loosely attach the BBK Y-Pipe halves with the supplied coupler. ***NOTE!!! Final tightening of this coupler will be done after all other components are aligned and tightened.***

### STEP 15

- Connect the flanges on the Y-Pipe to the headers using the supplied hardware.

### STEP 16

- Using the original clamp, connect the supplied Y-Pipe to the tailpipe section.

### STEP 17

- Tighten the coupler that connects the Y-Pipe halves.

### STEP 18

- Re-connect the spark plug wires.

### STEP 19

- Re-install the dipstick tube using the original bolt.



Join our Facebook page  
[www.facebook.com/bbkperformance](http://www.facebook.com/bbkperformance)



Follow us on Twitter  
[@bbkperformance](https://twitter.com/bbkperformance)



Check us out on Youtube  
[www.youtube.com/bbkperformance](http://www.youtube.com/bbkperformance)

GO TO NEXT PAGE

[WWW.BBKPERFORMANCE.COM](http://WWW.BBKPERFORMANCE.COM)

For any questions, email us:  
[tech@bbkperformance.com](mailto:tech@bbkperformance.com)

installation instructions

2

**IMPORTANT:** All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

INS-114

# Long Tube Headers & Matching Y-Pipe

## Part # 1694,16940



### STEP 20

***NOTE!!! You can chose to extend the oxygen sensor wiring, but its best to extend the wiring harness itself and not the oxygen sensor wiring as most oxygen sensors have special wires in them. BBK strongly recommends soldering the connection, then using the supplied heat shrink to insulate & protect the connections.***

- A. Determine how much longer your oxygen sensor harness needs to be and cut the appropriate lengths from the supplied wire. We have supplied enough wire to extend the front oxygen sensor harnesses 10 inches.
- B. Cut the supplied heat shrink into 16 1in sections.
- C. Cut and extend the oxygen sensor harness wires one at a time so the wires don't get mixed up. Be sure to slide 2 pieces of heat shrink over each wire as far away as possible from the area being soldered. Once the solder has cooled, slide a piece of heat shrink over the soldered area and use radiant heat from the soldering iron or heat gun to shrink it.

### STEP 21

- Re-establish all oxygen sensor connections, re-install the steering shaft and re-connect the negative battery terminal.
- After about 500 miles of driving, re-torque the headers bolts.



Join our Facebook page  
[www.facebook.com/bbkperformance](http://www.facebook.com/bbkperformance)



Follow us on Twitter  
[@bbkperformance](https://twitter.com/bbkperformance)



Check us out on Youtube  
[www.youtube.com/bbkperformance](http://www.youtube.com/bbkperformance)

[WWW.BBKPERFORMANCE.COM](http://WWW.BBKPERFORMANCE.COM)

For any questions, email us:  
[tech@bbkperformance.com](mailto:tech@bbkperformance.com)

installation instructions

3

**IMPORTANT:** All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

INS-114