


INSTALLATION INSTRUCTIONS

2018+ Jeep JL Console Insert #348

Please read and fill out the enclosed warranty registration card or register online at https://tuffyproducts.com/warranty-registration/ to activate your warranty.

PARTS CHECKLIST



SHIPPING PACKAGE CONTENTS

#10.1 Left Brace(Short)

(Included With Keys)



#10 Left Brace

#13.1 (2) ¼" Nylon Washer



#13.2 ¼"-20 x 5/8" Cap Screw



#11.1 Right Brace(Short)

#13.3 1/4"-20 Nylock Nut



#11 Right Brace

#13.4 (6) #10-32 Nylock Nut



#13.5 (6) #10-32 x 1/2" Screw

Tools needed for standard installation:

•Phillips Head Screwdriver •5/32" Hex Wrench


•3/8" End Wrench

•7/16" End Wrench


PLEASE READ ALL INSTRUCTIONS THOROUGHLY BEFORE STARTING INSTALLATION.

Important Note: Vehicles equipped with Selec-Trac or Rock-Trac All-Wheel Drive systems have a shallow center console and require the Short Braces(#10.1 and #11.1) to be used in Steps #6 and #8.


- 1. Remove all contents from the shipping box and confirm that you have all the components listed on Page 1.
- 2. Open the factory console lid and remove all contents (including the pad in the bottom of the OEM console).
- 3. Place the #348 Console Insert into the OEM console with the lock toward the front of the vehicle. A slight downward angle may be required, as the opening of the console is smaller than the inner profile.
- 4. Unlock and open the lid of the #348 Console Insert and lift it off the bottom of the console and install the #8 Left Fill Plate using (1) #13.5 Screw, and (1) #13.4 Nylock Nut. The Fill Plate should be inserted through the opening of the Console Insert, and then lifted into position between the wall of the console and the outer edge of the Console Insert collar. (See Figure 1)



5. Install the #9 Right Fill Plate using (1) #13.5 Screw, and (1) #13.4 Nylock Nut. As with the left side, the Fill Plate should be inserted through the opening of the Console Insert, and then lifted into position between the wall of the console and the outer edge of the Console Insert collar. (See Figure 2) *NOTE*: Screw is installed upward to provide temporary clearance for the next steps.





6. Move the #10 Left Brace or #10.1 Left Brace(Short) into position by slipping the hem over the lower horizontal flange of the Console Insert collar and rotating it so the mounting holes align. (See Figures 3 and 4)



7. Install (2) #13.5 Screws and (2) #13.4 Nylock Nuts to secure the #10 or #10.1 Left Brace in position. (See Figure 4)
Page 3 of 5 – RevA – Patent Rights Reserved

8. Move the #11 Right Brace or #11.1 Right Brace(Short) into position by slipping the hem over the lower horizontal flange of the Console Insert collar and rotating it so the mounting holes align. (See Figures 5 and 6)






9. Install (2) #13.5 Screws and (2) #13.4 Nylock Nuts to secure the #11 or #11.1 Right Brace in position. (See Figure 6)


10. Remove the #13.5 Screw and #13.4 Nylock Nut holding the #9 Right Fill Plate in place and reorient them as shown in

Figure 7.



Page 4 of 5 – RevA – Patent Rights Reserved

11. Assemble the lid support hardware as shown in Figure 8, using the #13.2 Cap Screw, #13.3 Nylock Nut, and (2) #13.1 Nylon Washers. Tighten the hardware in small increments so that the lid remains supported as you prefer (normally self-supporting at a 45-degree lid angle).



NOTE: Second nylon washer (#13.1 shown below assembly in Figure 8) slips between moving slotted part, and stationary body.

NOTE: Over time the friction that holds the lid in the open position may be reduced due to normal wear. To increase the friction, it is necessary to tighten the assembly. Tighten in small increments and test by opening/closing the lid until you have reached your preferred tension.

- 12. Confirm that all hardware has been sufficiently tightened.
- 13. Replace contents of console, the pad removed in Step 2 will cover the bottoms of the braces.