

# ***Installation Instructions for 70520, 70521 & 70522 Lava Mat Heat Shield***

## **Installation Instructions:**

### **Mounting**

- Lava Mat Heat Shield has a high temp adhesive back that can be adhered to almost any clean oil free surface. Clean surface with Isopropyl Alcohol or equivalent.
- Lava Mat Heat Shield can also be held in place with screws, rivets or stainless wire ties.

### **Specifications**

- Withstand radiant heat of up to 1200°F direct/continuous and 1800° intermittent.
- 0.007" thick and is easily cut to size with a pair of scissors.



**1-800-345-4545 [jeps.com](http://jeps.com)**