

940026K JEGSTER FUNNY CAR CAGE KIT

This funny car cage is shown below, (shaded parts), with a Jegster 12 point cage. The pieces are cut oversize to allow installation flexibility depending on driver position relative the main hoop, and to allow installation flexibility with cages other than Jegster. Please read all instructions and become familiar with the illustrations before starting installation. Fit the parts and tack weld in place only, until each part is positioned and checked with the seat and the driver in place.

Start with inner post 1. Fit the upper end to the main hoop first. See illustration B. Parts 1 and 2 should attach to a frame crossmember, (not included), or the floor with reinforcing plates. Fit both back braces to the main hoop and to the floor crossmember. Two versions of the back brace installation are shown in illustration C. The left version has most of the bend trimmed off before fitting to the cage main hoop and a small amount removed from the bottom. The right version uses most of the bend and has a larger amount removed from the bottom. Illustration D shows the outer front bar and the inner front bar. The ends of these bars to be trimmed before fitting to the halo and the cage side bar are shown in dotted lines. Next the top bar is fit between the main hoop and the inner front bar. See illustration E. The head rest tubes may not be necessary depending on the spacing of the FC cage main bars. See rule book. Two versions of head rest installations are shown in illustration F.

