

JEGSTER SEAT BACK MOUNTING BRACKETS

40485 for polyethylene seats

40486 for aluminum seats

40487 for all applications with seat positioned against cage cross bar

Determine the best bracket position to avoid interfering with the harness. Hold the bracket in place and mark the seat through the bracket holes. Drill $5/16$ holes through the seat. If mounting a polyethylene seat, use a hole saw to cut a hole in the front wall only of the seat back for bolt, washer, and wrench access. Weld the tabs to the cage cross bar. If using the 40487 bracket, weld the entire bracket to the cage bar.

